

## SETTING UP CUSTOMER-OWNED ROUTER

(our help desk does not support customer-purchased equipment, however, here is the IP address information necessary to make your connection)

NOTE: DO not connect router to ORANGE WALL jack. If you have already plugged into the orange wall jack – UNPLUG the ethernet cord. You may have to “reset” your router.

STEP 1: Connect 1 PC to the router (using 1 of 4 ports on right side)



STEP 2: Open Internet Explorer. In the address bar type:  
<http://192.168.1.1> to log into the router.

On screen:

USER NAME: leave blank (do not put any characters in this field)

PASSWORD: enter admin

Change Local IP address to: 192.168.0.1  
(replace 192.168.1.1)

Click on ‘Save setting’.

Reboot PC.

STEP 3: Using ethernet cord connect internet port to **ORANGE wall jack**.



other ports can be used to  
connect PCs directly to router